

Manual Mini Tutorett

```
-- Select Game --
> Classic Math
  Math Challenge
  Five Gangsters
  Random Answer
  Magic Number
  Q&A
  Setting
```

Using arrow key (Up and Down) to select the main manu

1.Classic Game is the Basic Math function. There will be five Games. (+, - x, / and Advance)

```
- Classic Game -
  Select Game: 1

  ( + )
```

Using arrow key (Up and Down) to select the game then Enter

```
*-----*
  Press Start to
  New Game
*-----*
```

To start playing game push Start keypad.

```
Level 1 [ L3 ] 27
  0+5 = 5

  Correct !
```

To continue new Game press Start Keypad
Going back to the manu push Menu keypad.
To win the game you have to pass to Level 10

2 Math Challenge game can select the answer from 1 upto 48.

```
Game Setting
  Select 1-48: 24
```

Enter the answer then push start keypad to start the game.

```
1234 24      [?]      53
```

For example if the answer is 24 and the question give you 4 numbers of 1234

The <S> House

You can play such as

```
1234 24      [?]      53
  1x2 = 2
  2x3 = 6
  6x4 = 24
```

If you can not find solution

1. If the time run out the game is over or
2. Press the Start keypad to get the equations but you will lost energy from 3 to 2

```
1234 24      [?]      53
  Press any key !
  [(1x2)*3]*6 = 24
```

The game will be over once you lost all of your energy or timeout.
To win the game you have to pass to Level 10.

3 Select Five Gangsters
Five Gangsters will random the answer for 5 number 6,12,24,36 and 48

```
*-----*
  Press Start to
  New Game
*-----*
```

Press Start keypad to start the game

```
7473 12      [?]      53
  7+4 = 11
  11-7 = 4
  3x4 = 12
```

If you can not find solution

1. If the time run out the game is over or
2. Press the Start keypad to get the equations but you will lost energy from 3 to 2

```
7473 12      [?]      53
  Press any key !
  [(7+4)-7]*3 = 12
```

The game will be over once you lost all of your energy or timeout.
To win the game you have to pass to Level 10

Brain Teasers

4 Select Random Answer
This game will random the answer for 1-48

```
*-----*
  Press Start to
  New Game
*-----*
```

Press Start keypad to start the game

```
7416 38      [?]      53
  7+1 = 8
  8x4 = 32
  32+6 = 38
```

If you can not find solution

1. If the time run out the game is over or
2. Press the Start keypad to get the equations but you will lost energy from 3 to 2

```
7416 38      [?]      53
  Press any key !
  [(7+1)x4]+6 = 38
```

The game will be over once you lost all of your energy or timeout.
To win the game you have to pass to Level 10

```
Please wait . . . -
  Level 1
```

* Remark some question may take long time, please wait in a few second.
Because Mini Tutorett will check all questions are doable, it will not allow the No combination.



5. Select Magic Number

xxxx	P N	[?3] 600
		(10)

This game will change player to find out the 4 Random Number. For example, If the Magic Number is 3670

xxxx	P N	[?3] 590
1234	0 1	(9)

This show you that 1234 is correct 1 digit but no correct position

xxxx	P N	[?3] 540
1234	0 1	(8)
5678	2 0	

The 2nd try, Player will know that 5678 is correct 2 digits and both of them are correct position

xxxx	P N	[?3] 502
1234	0 1	(7)
5678	2 0	
3679	3 0	

The 3rd try, Player will know the answer immediately

xxxx	P N	[?3] 480
1234	0 1	(6)
5678	2 0	
3679	3 0	
3670	4 0	

After player keyin 3670 then Mini Tutorett will show

Total Turn	3
	3670
	You win !
	Press start !

* Remark :
You can get help by press Start keypad, Mini Tutorett will give you one number with correct position. Once you use help [?3] will be [?2]

6. Q&A is not the game but this will help you to find out the solution

Game Setting
Select 1-48: 24

Enter the answer then keyin the 4 digits of your question.

Question/ Ans. 17
Key number : 1389
Solution of 1389
No combination

For example you select the answer to be 17 then keynumber 1389 Mini tutorett will find out the solution for you. No combination means 1389 can not make 17 by using only +, -, x and /.

7. Setting is function to control Minitutorett for Back Light and Sound Press Enter to change the status of Back Light and Sound




9x9

Sudoku



6x6



Tutorett & Mini Tutorett



Math Challenge



Matrix



English Challenge



Mini Tutorett

www.componet.co.th

บริษัท คอม โพนีท จำกัด

13/89 หมู่ 1 ถนนศรีนครินทร์ แขวงหนองบอน

เขตประเวศ กรุงเทพฯ 10250

Tel 082-3308920-22, Fax 082330-8058

www.componet.co.th